

Please read this leaflet carefully before start using neodymium magnets!
Important safety information for the responsible use of neodymium magnets.

Permanent magnets and materials, particularly neodymium, are technical products that require special precautionary measures before start using them.

We kindly ask you to forward this information to all employees, customers and other persons related to our products.
The company `magtivio B.V.` , rejects any responsibility caused by improper use.

Hazards from magnets



- Risk of injury by crushing
- Risk of injury by fragments
- Hazards caused by magnetic fields
- Pacemakers
- Magnetic data carriers (Credit cards, SD-Memory Cards etc.)
- Electric devices (mobile phones, computers, displays etc.)
- Fire danger
- Health hazards in contact with food and water

Handling

- Do not leave iron objects such as needles, knives, tools in the vicinity of magnets.
- The magnets can collide without control and damage other metal surfaces creating dust and splinters or cracking.
- Wear eye protection.
- Persons with a pacemaker should not come in contact with the magnetic field.
- Keep electric devices and data cards away from the magnetic field.
- The magnets must not be machined, drilled or cut.
- The resulting drilling / magnetic dust is extremely flammable.
- The magnets can not be glued or fixed with nails.
- Keep the magnets away from open flame and heat!
- The magnets have a coating of nickel, which by improper use may be removed or damaged.
- It is recommended not to put the magnets in contact with foods and beverages because of possible creation of metal ions in contact with water and liquid substances.

magtivio B.V.

Daelderweg 9
6361 HK Nuth | The Netherlands

Tel.: +31 (0)45 208 4810
Fax: +31 (0)45 208 4817
www.magtivio.com
info@magtivio.com



magtivio

PS0025-0021_Safety_leaflet_Neodymium_magnets